

REAR RIGHT PARKING BRAKE CABLE ASSEMBLY
CABLE MUST BE ROUTED THRU LEFT FRAME RAIL AND BEHIND
RH SHOCK ASSEMBLY AS SHOWN

